



Ordering example:

CBMZ 45 100-110 PU 6-8/3 T12

CBMZ 45:
 100: Type
 Stroke
 110: Reach X
 PU: Marking tool on the jaw, PO=marking tool on the swivel arm (PTH...= Type holder)
 6-8: 6 = letter height (mm) / 8 = number of digits
 3: last 3 digits automatically changing
 T02: Sensing system

Standard reach X:

140, 200, 300
 Further reaches on request.

Standard stroke:

100, 200
 Special strokes on request.

For further marking tools/type holder see data sheets "P...", "PTH".

Medium: Air, max. 8 bar, operation permitted with oil-free air.

*Tolerance for dowel holes $\pm 0,02$, for threaded holes $\pm 0,1$.

Ordering example Tünkers sensing system:

...T02 Inductive sensor 24 V, 2 outputs with integrated LED's