



## Spare Parts List

HKC 50, B

### Spare Parts


06/09

Pos.	Part-No.	Quantity	Description	Type	Flag <sup>1</sup>
10	214761	1.00	housing	HKC 50	
	205941	1.00	housing	HKC 50 B	
20	205929	1.00	clamp arm	HKC 50	
30	206363	1.00	clamping lever	HKC 50	
40	204321	1.00	lever	HKC 50	
60	202734	2.00	bolt	HKC 50	R
70	202735	2.00	bolt	HKC 50	R
80	200898	4.00	shim ring	PS 12/18 x 1 DIN 988	
90	203127	2.00	distance sleeve	E0 Ø12/18 x 22	
100	203128	2.00	distance sleeve	□ 14 x 25	
120	200434	3.00	hex. socket head cap screw	M 8 x 35 DIN 6912	
130	200977	3.00	securing spring washer	S 8	
140	201206	2.00	adapter sleeve	3 x 22 DIN 1481	R
150	201582	4.00	bush	B09 Ø 12/14 x 12	R
160	201561	2.00	bush	B09 Ø 12/14 x 8	R
170	211471	2.00	spring able thrust	M 8 x 16 KS	

### spare parts/accessories

Pos.	Part-No.	Quantity	Description	Type	
	205847	1.00	repair kit	HKC 50	

<sup>1</sup> R = included with repair kit





**TÜNKERS®**  
**SPANNSYSTEME**

Tünkers® Maschinenbau GmbH  
Am Rosenkoth 8 • 40880 Ratingen  
Postfach 10 17 16 • 40837 Ratingen  
Tel. 02102 4517-0 • Fax 02102 455808  
Internet [www.tuenkers.de](http://www.tuenkers.de)



## Spare Parts Drawing

HKC 50



**TÜNKERS®**  
**SPANNSYSTEME**

Tünkers® Maschinenbau GmbH  
Am Rosenkoth 8 • 40880 Ratingen  
Postfach 10 17 16 • 40837 Ratingen  
Tel. 02102 4517-0 • Fax 02102 455808  
Internet [www.tuenkers.de](http://www.tuenkers.de)